















<p><b>DSS 311 026</b></p>  <p>A: 20 C: 15 H: 2</p> <p>KIA</p> <p>165</p>	<p><b>DSS 311 137</b></p>  <p>A: 17 C: 7,7 H: 3</p> <p>TOYOTA 11176-26010</p> <p>166</p>	<p><b>DSS 311 138</b></p>  <p>A: 16 C: 7,7 H: 3</p> <p>MINI ONE 1.4D - TOYOTA 11176-33010</p> <p>167</p>	<p><b>DSS 311 139</b></p>  <p>A: 16,3 C: 7,3 H: 2</p> <p>DENSO 11176-30011</p> <p>168</p>
<p><b>DSS 311 567</b></p>  <p>A: 13 C: 7 H: 1,5</p> <p>DEUTZ</p> <p>169</p>	<p><b>DSS 311 577</b></p>  <p>A: 13,7 C: 7,2 H: 2,5</p> <p>RENAULT MEGAN CITROEN DCi 9001-850F</p> <p>170</p>	<p><b>DSS 311 578</b></p>  <p>A: 13,9 C: 7,3 H: 1,4</p> <p>7169-519</p> <p>171</p>	<p><b>DSS 311 579</b></p>  <p>A: 16,5 C: 10 H: 1,2</p> <p>UNIWERSALNA</p> <p>172</p>
<p><b>DSS 311 580</b></p>  <p>A: 16 C: 10 H: 2</p> <p>UNIWERSALNA</p> <p>173</p>	<p><b>DSS 311 209</b></p>  <p>A: 10 C: 6 H: 1</p> <p>COMMON RAIL STALOWA POD KRÓCIEC</p> <p>174</p>	<p><b>DSS 311 215</b></p>  <p>A: 15,8 C: 7,6 H: 3</p> <p>VW PDE 75/80</p> <p>175</p>	<p><b>DSS 245 201</b></p>  <p>A: 8 C: 7 H: 0,7</p> <p>VW PDE 75/80 RING</p> <p>176</p>

## Podkładki termiczne - LEGENDA

<p><b>TULEJKA OCHRONNA</b></p> 	<p><b>TULEJKA OCHRONNA</b></p> 	<p><b>ZGNIOTKA</b></p> 	<p><b>ZĄBKOWANA</b></p> 
<p><b>FREZOWANA</b></p> 	<p><b>NIETYPOWA</b></p> 	<p><b>ZWYKŁA</b></p> 	<p><b>STOŻKOWA</b></p> 

